



## Valve Velocity

Average valve velocity is calculated as follows:

$$V = \frac{288 \times D}{A}$$

V = Valve velocity, ft/min

D = Piston displacement, cfm

A = Product of lift and valve opening periphery, total for all valves in the cylinder

Velocities calculated by this method should be treated only as a general indication of valve performance.